

HOW TO USE

Insert hands between the infra-red sensors at the top of the Dyson Airblade™ hand dryer to initiate operation and airflow.

Move hands up and down slowly through the air to dry hands.

Remove hands and the unit will shut off.

CLEANING ADVICE

SURFACES

Make sure that all surfaces of the Dyson Airblade™ hand dryer are cleaned daily with a soft cloth and non-abrasive, non-caustic cleaning solution.

During normal use, there may be some gathering of water underneath the Dyson Airblade™ hand dryer. Please ensure that the unit and surrounding surfaces are wiped and cleaned regularly.

MAINTENANCE ADVICE

AIR INLET

Regularly check the air inlet at the base of the Dyson Airblade™ hand dryer to ensure that it is free from dust, debris and other particles. If the air inlet gets dirty simply remove dust, debris or other particles.

Make sure that all of the Dyson Airblade™ hand dryer's surfaces and the (4) sensor lenses are wiped down daily to maintain uninterrupted operation of the unit.

Also visit the website at www.dysonairblade.com

TESTING

Make sure that power is switched on to the unit.

Insert hands between the infra-red sensors at the top of the Dyson Airblade™ hand dryer to initiate operation and airflow.

Move hands up and down slowly through the air to dry hands.

Remove hands and the unit will shut off.

TROUBLESHOOTING

IMPORTANT: TURN OFF POWER BEFORE SERVICING.

Note: Please try and have model & serial number available before calling the Dyson Helpline.

These can be found on the rating plate of your hand dryer.

The Dyson Helpline can be contacted by calling 1-888-DYSON-AB.

Problem	Action	If Problems Persist
The Dyson Airblade™ hand dryer fails to start.	Check to make sure the unit is connected and wired correctly, and that it is turned on.	Call Dyson Helpline at 1-888-DYSON-AB.
The Dyson Airblade™ hand dryer is turning on and off erratically.	Check that the sensor lenses are clean.	
The Dyson Airblade™ hand dryer sometimes cuts out when in use, but resumes operation after a period of time.	Check that the air inlet at the base is clean and free of dust. If the air inlet is dusty, simply remove dust.	
Air is coming out of the front or back of the unit.	Check for and remove any obstructions.	
Unit is making a rattling noise.	Ensure that none of the tamper proof screws are loose. Tighten if necessary.	
Unit continues to run after user removes hands.	Unit runs for approximately 2 seconds after hands are removed - The unit is operating correctly. There is a time delay function built into the unit. Unit runs for longer than 5 seconds after hands are removed- Check to ensure that the infra-red sensors are not obstructed or dirty.	
Unit is not drying hands as fast as it used to.	Verify that the air inlet is not blocked or obstructed. If necessary, clean the air inlet.	
Unit runs for a couple of seconds and then turns off.	Verify that the air inlet is not blocked or obstructed. If necessary, clean the air inlet.	
Water collects on floor.	During normal use, there may be some gathering of water underneath the Dyson Airblade™ hand dryer. Please ensure that the unit and surrounding surfaces are wiped and cleaned regularly.	

Warranty

Thank you for choosing to buy the Dyson Airblade™ hand dryer.

If you have a question about the Dyson Airblade™ hand dryer, please call the Dyson Helpline at 1-888-DYSON-AB. Please make sure you have your serial number and purchase information ready. The serial number can be found on the rating plate of the hand dryer.

Typically problems can be handled over the phone by our trained technical support staff. If service is required (which may include replacing a defective part), our staff will coordinate and discuss options to have your machine serviced by Dyson or its authorized agent.

If your machine is covered under warranty, and the repair is covered, Dyson will provide replacement parts at no cost to the unit owner (which can be installed by Dyson or its authorized agents for additional costs at prevailing rates) for a period of 5 years from date of purchase (or date of delivery, whichever is later).

In addition, during the 1st year, this warranty provides at no extra cost to unit owner all the labor necessary to ensure that your Dyson Airblade™ hand dryer is in proper operating condition.

All repair work pursuant to this warranty must be carried out by Dyson or its authorized agents. Repairs or replacement of your Dyson Airblade™ hand dryer under any Dyson warranty will not extend the period of any warranties herein.

The product owner is responsible for securing access to the product during any Dyson warranty repair. Any parts replaced or removed by Dyson or its authorized agents during the first year will become the property of Dyson.

5 Year Parts Limited Warranty

All original factory parts of your Dyson Airblade™ hand dryer are warranted against defects in material and workmanship when used in accordance with the Owner's Manual for a period of 5 years.

The 5 year parts limited warranty commences on the date of purchase (or on the date of delivery, whichever is later).

The 5 year parts limited warranty will expire on the fifth anniversary of its commencement. The unit owner must provide proof of purchase before any replacement parts will be provided for repair pursuant to this warranty.

Without this proof of warranty, the owner is liable to pay for any parts on the product by Dyson or its authorized agents at the prevailing rate.

All functional factory replacement parts can be installed by Dyson or its authorized agents for additional costs at the prevailing rates.

Additional 1st Year Labor Limited Warranty

This warranty commences on the date of purchase (or on the date of delivery, whichever is later). The 1 year limited labor warranty will expire on the 1st anniversary of its commencement.

In addition, during the 1st year, this warranty provides at no extra cost to unit owner all the labor necessary to ensure that your Dyson Airblade™ hand dryer is in proper operating condition.

All repair work pursuant to this warranty must be carried out by Dyson or its authorized agents. Any labor charges involved with defective replacement parts after the 1st year limited labor warranty expires are the sole responsibility of the product owner.

THE 5 YEAR PARTS LIMITED WARRANTY AND THE ADDITIONAL 1ST YEAR LABOR LIMITED WARRANTY ARE SUBJECT TO THE FOLLOWING:

What is not covered by the 5 year parts limited warranty or the 1 year labor limited warranty. Dyson shall not be liable for costs incurred as a result of:

Machines not purchased by the original purchaser or machines not purchased from an authorized dealer.

Any damage (accidental or otherwise) or faults caused by negligent use or care, misuse, neglect, careless operation, failure to properly repair or maintain the machine, or handling the machine in a manner not in accordance with the Dyson Airblade™ Owner's Manual.

Use of parts not in accordance with the Owner's Manual of the Dyson Airblade™ hand dryer. Blockages, other than those caused by soap and water in normal use. In case of other types of blockages please refer to the Troubleshooting section of the Owner's Manual or call the Dyson Helpline for advice.

External causes such as weather, electrical outages or power surges. Repairs or alterations carried out by unauthorized parties or agents.

Any matter that results from improper, inaccurate or otherwise faulty installation. Use of parts not supplied by Dyson or not supplier approved by Dyson, or not installed by Dyson or an authorized agent, or not fitted or installed in accordance with Dyson's instructions. Repairs or alterations not carried out by Dyson or an authorized service agent.

Failures caused by acts of God or circumstances outside of Dyson's control. If you have any doubts as to what is covered by your warranties, please call the Dyson Helpline at 1-888-DYSON-AB.

Warranty Service

Please fill out and return the Product Registration Form, or register online at www.dysonairblade.com or call the Dyson Helpline at 1-888-DYSON-AB.

Before any service can take place, the terms of both warranties require that you contact the Dyson Helpline with your serial number, and the date of purchase or delivery (which ever comes later).

Limited Warranty Information

Please keep your purchase receipt or information in a safe place to ensure that you have this information available.

All covered repair work will be carried out by Dyson or its authorized agents. Any replaced defective parts will become the property of Dyson during the first year.

Service under any Dyson warranty will not extend the period of any warranty. If your machine is not functioning properly, please call the Dyson Helpline at 1-888-DYSON-AB. Most issues can be resolved over the telephone by our trained helpline and technical support staff. If this is not possible, Dyson will arrange for your Dyson Airblade™ hand dryer to be repaired pursuant to the terms of the appropriate Dyson Airblade™ hand dryer applicable warranty.

Other Limitations and Exclusions of Warranties

Except as expressly stated above, Dyson makes no representations or warranties relating to your Dyson Airblade™ hand dryer, and Dyson disclaims all warranties, express or implied, statutory or otherwise, including but not limited to the warranty of merchantability or fitness for a particular purpose. This limitation is not allowed by some states and so this limitation may not apply to you.

Your remedy for breach of the warranties is limited to the warranties described above. Dyson will not be liable for any special, indirect, incidental or consequential damages (including loss of profits) you may incur in connection with your purchase and use of your Dyson Airblade™ hand dryer. This limitation is not allowed by some states and so this limitation may not apply to you.

In no event shall Dyson be liable for any damages arising directly or indirectly from any tort (including negligence or gross negligence) committed by Dyson or its affiliates, agents or employees, or for any breach of contract, fundamental or otherwise.

These warranties give you specific legal rights. You may have other rights which may vary by state.

The Dyson warranties herein described are not transferable.

Contacting Dyson

Dyson Helpline can be contacted by calling 1-888-DYSON-AB. Please make sure you have your serial number and purchase information ready.

The serial number can be found on the rating plate of the hand dryer. For further information about the Dyson Airblade™ hand dryer, please visit www.dysonairblade.com




TESTED, CERTIFIED, HYGIENIC
PROBADA, CERTIFICADA, HIGIÉNICA

dyson airblade

OWNER'S MANUAL MANUAL DEL PROPIETARIO

AB AB
02 04



www.dysonairblade.com

JN.22774 PN.17173-02-01 09.10.08

